

NAMZ Brake Switch "RTI" Harness Kit
Part Number: NBSH-2418

Installation Instructions:

1. BE SAFE, DISCONNECT THE BATTERY FIRST!
2. Locate the rear brake switch usually located on the right side of a big twin near the transmission end cover.
3. Follow the wire from the switch up to where it begins to go into .
4. Slide on the stainless steel braiding. Fasten one end using black electrical tape. (Not included)
5. While holding the taped end, stretch the stainless towards the opposite end and fasten. (This will make the stainless tight against the harness)
6. Crimp on new #10 insulated ring terminal. (Supplied)
7. Slide the 5/16" clear heat shrink loom over the stainless harness.
8. Proceed to shrink the loom using a heat gun. (NOTE, do not over heat the clear loom! Too much heat can cause the loom to tear.)
9. Place the 1" black fastener ends over the area where the stainless braiding ends to hide the seams.
10. Proceed to shrink the fastener ends in place.