

NAMZ Handlebar “DIY” Switch Braids
Part Number: NHCH-20 or 40DIY

Installation Instructions:

1. Remove existing black wire loom on handlebar switch harness.
 2. Slide on the black 3/8” heat shrink loom over the bare harness.
 3. Proceed to shrink the loom using a heat gun.
 4. Slide on the stainless steel braiding. Fasten one end using black electrical tape. (Not included)
 5. While holding the taped end, stretch the stainless towards the opposite end and fasten. (This will make the stainless tight against the harness)
 6. Slide the 1/2” clear heat shrink loom over the stainless harness.
 7. Proceed to shrink the loom using a heat gun. (NOTE, do not over heat the clear loom! Too much heat can cause the loom to tear.)
 8. Place the 1” black fastener ends over the area where the stainless braiding ends to hide the seams.
- Proceed to shrink the fastener ends in place.