

NAMZ Regulator “DIY” Braid Kit
Part Number: NRH-4801

Installation Instructions:

1. BE SAFE, DISCONNECT THE BATTERY FIRST!
2. Locate the regulator circuit breaker, loosen nut and remove the harness.
3. Cut off the factory ring terminal.
4. Slide on the stainless steel braiding. Fasten one end using black electrical tape. (Not included)
5. While holding the taped end, stretch the stainless towards the opposite end and fasten. (This will make the stainless tight against the harness)
6. Crimp on new #10 insulated ring terminal. (Supplied)
7. Slide the 5/16” clear heat shrink loom over the stainless harness.
8. Proceed to shrink the loom using a heat gun. (NOTE, do not over heat the clear loom! Too much heat can cause the loom to tear.)
9. Place the 1” black fastener ends over the area where the stainless braiding ends to hide the seams.
10. Proceed to shrink the fastener ends in place.