



### NAMZ Custom Cycle Products, Inc

1440 Ulmer Avenue  
Oreland, PA 19075

Technical Support is available Monday-Friday, 9am-5pm EST via email at [tech@namzccp.com](mailto:tech@namzccp.com) or call us at 1-877-277-NAMZ.

Part Number: NTBW-J04, J08, J12, J15



**Fitment: NTBW-J04, J08, J12, J15:** 2016-Up Softail, Street Glide, Road Glide, Road King and Ultra Models ONLY

**This product is intended:** NAMZ Plug-N-Play Throttle-By-Wire Extension comes ready to install at either 4", 8", 12" or 15" lengths. This harness provides an easy way to extend the OEM Throttle-By-Wire in your handlebars without having to cut, strip, crimp or solder. All that work is done for you by the professionals. Installs in minutes and is a MUST HAVE to make your handlebar extension job with Throttle-By-Wire go that much quicker and smoother. This extension kit is 100% Plug-n-Play, manufactured here in Philadelphia, PA and uses OEM spec connectors small enough to go through handlebars with ease.

### What is included in this kit?

- (1) Plug-N-Play Throttle-By-Wire Extension Harness (4", 8", 12" or 15")

### Recommended tools:

- Phillips Head Screwdriver
- Small Flat Heat Screwdriver (or straight pick tool)

### WARNING!

*This product should be installed by a professional motorcycle technician or reputable shop/ dealership.*

*Improper installation may result in loss of throttle-by-wire functions or cause "limp mode".*

### Installation instructions:

1. Remove the seat and disconnect the negative battery cable.
2. Before you remove your OEM handlebars, locate and disconnect all connections (Controls, switches, throttle-by-wire, heated grips, etc.)
3. The Throttle-By-Wire harness utilizes (1) small 6-Position White Connector.
4. Disconnect, the OEM Throttle-By-Wire harness using a small flat head screwdriver (or straight pick tool) gently depressing the release tab on top of the connector while easily pulling the two connectors apart.

*Note: You can remove the twist grip assembly from the handlebars.*

5. Simply plug our extension harness in between the OEM Throttle-By-Wire connection and reinstall into the new handlebar. *(It is recommended to route all your handlebar wiring along with the extended throttle-by-wire harness into your new handlebars before they are mounted on the motorcycle).*
6. Use caution when fishing the throttle-by-wire harness as the connector and terminals can easily become damaged while routing through the handlebar. **NOTE: DO NOT pull our harness by the connector, DAMAGE will occur, and warranty will be voided. Tape onto the harness!**
7. Ensure ALL handlebar connections are reconnected to their respective locations.
8. Reconnect negative battery cable and test for functionality and codes accordingly.