

NAMZ Off-Road High Beam Remote Activation Relay
(2014-UP Polaris RZR)

Part Number: **OR-P-HBR-R**

1. Remove Hood, and locate desirable location for relay.
2. Mount relay on firewall with included self-tapping screw.
3. Locate and unplug the passenger side headlight harness. Then plug our harness in-between.
4. Attach Fused Red wire to factory BATTERY power post under hood.
Note: The BATTERY power post under the hood requires a separate harness to provide power to it. NAMZ Part Number: **OR-P-PWR-R**
5. Attach desired accessory power to Orange wire on the NAMZ harness, using the supplied heat shrinkable connector.
(Shrink connection with heat gun)
6. Ensure all connections and wiring are secured using supplied wire ties.
7. Test function of accessory: Turn key to on position and headlight switch to high beam, the accessory should now turn on and off with high beam.

Problems? Questions? Send us an email first! Info@namzccp.com