

NAMZ Off-Road Power Tap Harness for License Plate Light or Whip Light
Fits: 2015-UP Polaris RZR 1000
*Part Number: **OR-P-PTH-01-R***

1. Turn vehicle off, remove key, and disconnect negative battery cable.
2. Disconnect tail light connector located in the driver side rear of the vehicle, next to the air intake.
3. Connect our harness in-between the taillight connection.
4. Rout the accessory wires from our harnesses to either Whip light or License Plate Lights.
5. Use the (2) provided heat shrinkable Butt Connectors and connect your new light(s).
6. The accessory wires connect to your light as follows:
Red = Power
Black = Ground
7. Use provided cable ties to ensure all wires are routed away from any moving parts and pinch locations.
8. Test your new added light, and inspect all connections and wiring for proper installation.

Problems? Questions? Send us an email first! Info@namzccp.com