

NAMZ Off-Road Power Tap Harness for Stop/Tail light
Fits: 2015-UP Polaris RZR 1000
Part Number: **OR-P-PTH-02-R**

1. Turn vehicle off, remove key, and disconnect negative battery cable.
2. Disconnect tail light connector located in the driver side rear of the vehicle, next to the belt cover.
3. Connect our harness in-between the taillight connection.
4. Rout the accessory wires from our harnesses to either a Third Brake Light, LED Taillight, Whip Light, or License Plate Light.
5. Use the (3) provided heat shrinkable Butt Connectors and connect your new light(s).
6. The wires from our harness connect to your light as follows:
Red = Running Light
Orange = Brake Light
Black = Ground
7. Use provided cable ties to ensure all wires are routed away from any moving parts and pinch locations.
8. Test your new added light, and inspect all connections and wiring for proper installation.

Problems? Questions? Send us an email first! Info@namzccp.com