

NAMZ Oil Sending Switch “RTI” Harness Kit  
*Part Number: NOSSH-1801*

Installation Instructions:

1. BE SAFE, DISCONNECT THE BATTERY FIRST!
2. Our harness cover comes ready to install. It is intended for Evolution© style engines only.
3. Locate Oil Sending Unit and remove 5/16” nut on top of the unit.
4. Once disconnected, cut off the ring terminal and remove the wire loom from the wire harness.
5. Now that the wire is exposed, slide on our braided harness cover.
6. Strip a 1/4” of the jacket off the wire and crimp on the ring terminal, included.
7. Once the ring terminal is installed, tighten on the 5/16” nut. (NOT TOO TIGHT OR UNIT WILL CRACK!)
8. Be sure to test unit before reconnecting the battery.