



NAMZ Custom Cycle Products, Inc

1440 Ulmer Avenue
Oreland, PA 19075

Technical Support is available Monday-Friday, 9am-5pm EST via email at tech@namzccp.com or call us at 1-877-277-NAMZ.

Part Number: NICS-X15



Fitment: NAMZ Indian Chief Speedometer Extension Harness, fits: 2022-Up Indian Chief Models, 100% plug-n-play!

This product is intended: The NAMZ Indian Chief Speedometer Extension harness is like all of our 100% plug-n-play wiring harnesses, simple to install! With this harness, it will allow for taller bars, taller risers or the relocation of your speedometer. We make it really easy for you to do it right! All NAMZ wiring products are built in our Pennsylvania location, 5-days a week with pride.

What is included in this kit?

- Complete wire extension kit with installed terminals and connectors

Recommended tools:

- Needle Nose Pliers
- Universal pick tool or small flat screwdriver

WARNING!

This product should be installed by a professional motorcycle technician or reputable shop/ dealership.

Improper installation may result in loss of handlebar switch functions.

Installation instructions:

1. Disconnect the negative battery cable before you begin.
2. In order to disconnect the speedometer connector you will need to remove the fuel tank. *(Consult your service manual for proper instructions.)*
3. Once the fuel tank is removed, locate the speedometer harness until you find the small, white 8-position connector.
4. Simply disconnect the connector using a small pick tool or flat screwdriver to depress the top tab.

NOTE: This connection is where our harness extension will attach.

5. Now that the harness is disconnected, plug in our extension harness in between the factory connection. This will add 15-inches to the OEM speedometer harness.

NOTE: Before re-installing the fuel tank, reconnect the battery and check that the speedometer functions properly.

6. If the speedometer works properly, turn off the ignition and reinstall the fuel tank following the OEM service manual.
7. Remount your speedometer and test all functions before you are complete.